†Orayvino Installation Procedure



Please take one for free using the adapters! Fits almost all faucets

The Adapter Set is included inside of the box.

Check to see your faucet size using the measure.



Faucets which accept the unit









Available to remov the aerator cap








- *1 Optional part (free) may be needed for some faucets.
- *2 Attachment tool may not be included for some products. Please request for optional part by asking your local sales representative.

Make sure the length of spout is more than 15mm when using A-type and D-type



torayvino — easy to install on your faucet!














B-type

D-type

22mm





ACAUTION Faucets which DO NOT accept the unit







- Leaks resulting from breakage of spout or spout parts are not covered by our guarantee.
- When a plastic insulation cap is attached to the end of the spout, water may leak from the faucet or the water purifier may not fit the faucet or the insulation cap may be broken, depending on the faucet type and condition.
- If the faucet is not tight enough, excessive load on the faucet may cause water to leak from the attachment part, faucet or the plumbing system.

Faucet types or installation instruction are also available online.

More information about TOTAYVING! www.torayvino.com/en/ torayvino Go-

